



Installation Manual

AS-6111Q

Motion Entry Alert



Installation and Important Notes:

1. This device is designed for motion alerts only. It is not designed to be a security device, and should never be used for security purposes.
2. Note that the sensor operates by detecting sudden changes in visible light and is not suitable for areas of total darkness or facing a strong light. It is suitable for indoor locations only—do not install where it could be exposed to moisture, extreme temperatures, or direct sunlight.
3. Mounting – For use as a door annunciator, mount on the wall next to a door frame with the sensor hole facing the door. However, it can be installed anywhere someone is expected to pass. The normal installation height is about 20"~40" (50~100 cm) above the floor and the detection range is 10ft (3m).
4. The sensor can be installed using adhesive tape (included) applied to a clean, dry, smooth surface. For more permanent installation using the included screws, first remove sensor from bracket by carefully expanding the arms of the bracket until the sensor can be pulled free. Install the bracket using the two screws.
5. Carefully remove the battery cover by pressing on the cover and sliding outward. Install the correct batteries (3 AAA batteries, not included) using correct polarity as indicated and replace the cover.
6. Re-install the sensor to the bracket. Turn on the sensor adjust the direction.
7. When the batteries run low, the device will frequently activate. In this case, replace the batteries.
NOTE: Replace all three batteries with fresh ones at the same time when needed.
8. When not used for long periods of time, remove the batteries to protect the internal electronics.

Specifications:

Power	1.5VDC AAA batteries x3 (not included)	
Current	Standby	Under 0.05mA@4.5VDC
	Active	Under 85mA@4.5VDC
Low battery indicators	Device will repeatedly activate	
Input signal	CDS sensor	
Output signal	Doorbell sound	
Sensor range	10ft (3m) at 20"~40" (0.5~1 m) height	
Material	ABS plastic, white	
Dimensions (with bracket)	3 ³ / ₈ "x3 ³ / ₈ "x2" (85x85x50 mm)	
Weight	3-oz (84g)	

*Requires 3 AAA batteries (not included)

Parts List:

- 1x Sensor
- 1x Bracket
- 2x Mounting screws
- 1x Adhesive mounting tape



WARRANTY: This SECO-LARM product is warranted against defects in material and workmanship while used in normal service for 1 (one) year from the date of sale to the original customer.